PRODUCT DATA SHEET



805ET LEAD DUST REMOVER ENVIROTOWELS

SENTINEL 805ET LEAD DUST REMOVER ENVIROTOWELS

Sentinel Lead Dust Remover Envirotowels are the latest technology in cleaning and removing lead dust. They are designed to be used for pre-cleaning prior to removal, encasement or encapsulation and for final clean-up following lead abatement. Each towel is ready-to-use and soaked with a solution of Sentinel 805, a phosphate free, lead specific cleaner. Designed with chelating agents to bind with lead contaminates so the premium towels can wipe and lift them from hard surfaces. Each pail contains 270 towels which are protected from contamination within the container.



Ready To Use / Cleans Lead Dust / Convenient Towels

800-373-0633 or www.senpro.com

PRODUCT DATA SHEET



FORMULA 805ET Lead Dust Remover ENVIROTOWELS

READY TO USE / CLEANS LEAD DUST / CONVENIENT TOWELS

Product Description

Sentinel Lead Dust Remover Envirotowels are the latest technology in cleaning and removing lead dust. They are designed to be used for pre-cleaning prior to removal, encasement or encapsulation and for final clean-up following lead abatement. Each towel is ready-to-use and soaked with a solution of Sentinel 805, a phosphate free, lead specific cleaner. Designed with chelating agents to bind with lead contaminates so the premium towels can wipe and lift them from hard surfaces. Each pail contains 270 towels which are protected from contamination within the container.

Application Information (Always follow product label instructions for best results)

Usage Guidelines:

Follow all Local, State and Federal Regulations pertaining to the cleanup and removal of lead dust as well as for the disposal of contaminated wipes and containment supplies. Wear PPE appropriate not only for the cleaning solution but also for the lead hazards present during cleanup activities. Wash hands and face before eating, drinking, smoking or any other activity.

Following HUD and EPA guidelines, personal belongings should be cleaned and removed from the space. Prior to wet cleaning all surfaces should be vacuumed with a HEPA filtered vacuum.

Directions For Use:

Break tab on the side of the pail and remove the lid. From the center of the roll, pull up corner of the first towel, twist to a point and thread through the slot on the underside of the lid. Firmly push the lid back on the pail. Open cap on the pail lid and tear off towel at perforation.

Working ceiling to floor and towards the door, wipe all surfaces, including ceilings, walls, floors, windows, doors, fixtures, cabinets, etc, until clean. Fold contaminated towel surface onto itself and wipe with clean side. Each clean towel surface can be used to clean up to 4 sq. feet of surface. Rinse with clean water.

Specifications:

Solution:

Physical state: Liquid Appearance: Clear

Color: None Odor: None pH: 5.75 - 6.75

Boiling Point: >212° F. Flash Point: None to boiling

Towel:

Dimensions: 10" x 13"

Count: 270

